

COMBINES DINING TABLE
SAFETY, ASSEMBLY AND MAINTENANCE INSTRUCTIONS

Please read the instructions carefully and retain for future use.

**Manufacturer is not responsible for any faults or damages caused by misuse
(not following these instructions).**

If you have any questions concerning the product, please do not hesitate to contact us.

CONTENTS

Table top and 2 x stretcher attached to the top (including 6 screws)

2 x cross stretcher

4 x leg

2 x pre-assembled ratchet strap

2 x measuring wedge

SAFETY AND MAINTENANCE INSTRUCTIONS

General

- Table is for indoor use only.
- Handle all the parts carefully.
- At least two adults are required to lift the table.
- Do not scratch the surfaces.
- Remove all the liquids immediately.

Top

- Read the table top care and maintenance instructions at:
www.fenixforinteriors.com/en-GB/cleaning/everyday-cleaning
www.arpaindustriale.com/en/hpl/cleaning

Straps

- If you notice slash or other damage on the straps, do not use the product. Send us a photo (antti@anttituomi.com) and we estimate the damage.
- Clean the straps with a damp cloth whenever necessary.
- Please note that direct sunlight exposure might fade the colour of the straps.
- There is no need to re-tighten the ratchet after correct assembly unless you notice some loosening with the structure.

Solid wood parts

- On a daily basis you can clean the wooden parts with a damp cloth using organic cleaners.

- The solid wood parts are treated with oil mixture. To maintain the look you should re-oil the parts in every 1 or 2 years or in case the wood appears dry. You should disassemble the table before re-oiling. Remove also the short stretchers. Re-oil all the wooden parts with natural matte wood-oil or wax. First sand lightly with a very fine sandpaper following the grain direction. Then treat the surface with a natural matte wood oil or wax and allow it to absorb for 15 minutes. Wipe away all the excess oil and polish the surface with a clean cloth.

Remember to read the oil manufacturers instructions before use also.

Other

- Tighten the screws in the stretchers with Allen key every two years or if you notice some loosening.

Assembly instructions

1. Open the package table top upside down.
2. Remove the packaging materials.
3. Carefully push one leg at the time into the cross stretcher. Prevent the stretchers from moving. You can use a rubber mallet if necessary. Take care that all the legs are installed straight so that there is no space between the legs and the stretchers.
4. Turn the cross stretchers so that the legs set to the round slots on the pre-assembled stretchers.
 5. Tighten the straps lightly with the ratchet however so that the straps grasp the legs.
 6. Use the measuring wedge to check the straps are straight. Straighten if necessary.
 7. Tighten the straps using the ratchet.
8. Push both legs in the other end simultaneously and slightly outwards. If the legs seem loose, tighten the ratchet 1-2 steps more and try again. Repeat the same actions with the other end. Please avoid unnecessary use of force. It might break the ratchet.
9. Push the measuring wedge between the strap and the stretcher narrow head first. One wedge for each end.
10. Turn the table around lifting both ends simultaneously (Do not turn the table alone!). The legs might slide a bit on the stretchers while turning. Don't mind that because the legs will set into their places when the table is fully turned. If the legs appear to slide very much or completely out of their slots do not turn, the straps are too loose! Tighten the straps before continuing.
11. After the table is turned, test that it feels firm. If it feels wobbly remove the wedges and tighten the ratchet 1 more step. Put the wedges back and try again. Repeat until the table stands firm. For this you don't have to turn the table upside down.
12. If the floor is uneven, straighten the table by adding extra felt under the leg which is not touching the floor.

Thank you for reading and following the instructions! Please contact antti@anttituomi.com if you need further instructions. We'll help you!

www.tuomifurniture.com